



## THINK SAFETY !

- NEVER USE A HEATER IN YOUR AMERISTEP® BLIND - UNVENTED FUMES COULD CAUSE SICKNESS OR DEATH
- NEVER EXPOSE YOUR BLIND TO ANY OPEN FLAME. THIS PRODUCT IS NOT FIREPROOF
- NEVER SHOOT THROUGH THE TSC WINDOWS WITH A FIREARM SPARKS OR FLAME FROM THE MUZZLE COULD IGNITE THE MATERIAL
- NEVER SHOOT EXPANDABLE BROADHEADS THROUGH THE TSC WINDOWS - THE MESH MAY CAUSE PREMATURE OPENING OF THE BLADES. USE FIXED BLADE BROADHEADS ONLY
- FOR BEST ARROW FLIGHT THRU TSC WINDOWS, ALIGN BROADHEAD BLADES WITH FLETCHING
- NEVER ALLOW CHILDREN TO PLAY WITH THIS PRODUCT WITHOUT ADULT SUPERVISION
- NEVER ALLOW MATERIAL TO COVER YOUR FACE. IT CAN CAUSE SUFFOCATION AND DEATH
- NEVER ALLOW ANYONE TO USE LIGHTED CANDLES, MATCHES OR OTHER SOURCES OF FIRE NEAR THIS PRODUCT
- ALSO AVAILABLE IS OUR BLAZE ORANGE TANGLE® SAFETY CAP (Sold Separately)
- **ULTRAVIOLET (UV) LIGHT WARNING:**  
Ultraviolet light breaks down lightweight fabric fibers (and almost any synthetic material). The material will fade (discolor), lose strength and eventually disintegrate if left in prolonged sunlight. To extend the life of your Ameristep product avoid leaving it out in direct sunlight for long periods of time. Set up your portable ground blind or accessory in a shady spot whenever possible to extend the product life.

## STORAGE & TIPS

- Store your Blind in a cool dry place - free native brush, dirt and any debris
- Never store your Blind wet or damp
- Avoid leaving your Blind outdoors for extended periods of time as it will cause unnecessary fading of the material if left in direct sunlight.
- To stop any leakage, use seam sealer on all seams and silicon spray on seams/sidewalls.
- To store your TSC windows, avoid wrinkles and creases that could significantly reduce visibility.
- To aid in folding blind, remove the floor and window curtain is all the way up



# THE RINGER BLIND

*Instruction Manual*



See our full line of accessories and Replacement Parts at: [ameristep.com](http://ameristep.com)

**Be sure to follow these guidelines for using your DOMINATOR  
READ AND UNDERSTAND ALL INSTRUCTIONS and WARNINGS FIRST**  
Any questions or confusion regarding the use of this product contact our  
Customer Service Department at Ameristep® (810) 686-4035 before using.



P.O. Box 189 • 901 Tacoma Court • Clio, MI 48420 • 810-686-4035 REV. 2/06

## THE RINGER SET UP INSTRUCTIONS



**Step 1:** Remove The Ringer Blind from the carrying case.

**Step 2:** Hold folded blind away from body, face and any other person. Let go of one side. The Ringer will pop open to form two large circles. They will lay flat on the ground (shown right).



**Step 3:** Lift the top ring so that you can find the fiber pole pockets located on the top and bottom rings, insert all of the fiber poles into the pole pockets so that blind will stand on its own.



**Step 4:** Place fiber poles into pole pockets on the top and bottom of the circles.



**Step 5:** Stake through grommets located in ground straps with tent stakes provided.


### PARTS LIST:

- 1 Ringer Blind
- 1 Camo Carrying Case
- 4 Tent Stakes
- 4 Fiber Poles

## THE RINGER TAKE DOWN INSTRUCTIONS



**Step 1:** Remove the fiber poles from the Blind.



**Step 2:** Once the fiber poles are removed, stand the flattened Ringer blind on end and place your hands, one at 10 o'clock and the other at 2 o'clock.



**Step 3:** Take your hands and begin to push downward. Once the center starts to fold, continue pushing until it resembles a "U" shape.



**Step 4:** While still in the "U" Shape, rotate your wrists inward towards your body and push the nose of the blind into the fold.

**Step 5:** Now tuck your right hand under your left hand and push down until the rings lay flat.



**Step 6:** Hold firmly the flattened blind and insert into carrying case.